

## Instructions on how to operate a manual smoke vent

### 58-59 Hyde Park Gate

The below is a picture of the manual switch which can be used to open the smoke vents at the top of the staircase during a fire. These switches are located on the ground floor by the entrance door.

Push in both break glass call points to activate the smoke vents – depress the black circle in the centre of the call point.

